

# Zehnder NOx Filter

Cleaning Guide

always the best climate

1

Remove the access panel from the unit by undoing the series of screws retaining the panel in place.

2

Withdraw the Filters individually from the unit by moving the retaining swivel catch to one side (Fig. A). Two checks are available to test the Media condition:

1. The NOx filters
2. Using a Media sample to carry out a Residual Capacity Test (RCT) in the laboratory

3

Remove the Pre-Filter and replace with a new Filter every 6 – 12 months.

4

After the Pre-Filters have been removed, re-install the replacement NOx Filter Cells into the unit and move the swivel catch to retain them in place.

5

Replace the access panel with the securing screws.

