



GUIDE DE POSE DES RADIATEURS
PLAATSINGSWIJZE VAN DE RADIATOREN
FITTING INSTRUCTIONS TVXD
ISTRUZIONI PER L'INSTALLAZIONE DEI RADIATORI
GUIA DE INSTALACION DE RADIADORES
BEFESTIGUNGSHINWEISE HEIZKÖRPER




Watts	L	H	A	B
750	800	442	340	68
1000	1100	442	640	68
1500	1500	442	1040	68
1000	800	590	340	216
1250	1100	590	640	216
1500	1300	590	840	216
2000	1500	590	1040	216







HX - HXD - MXD




VX - VXD



VLX ...



VLX ...








**GUIDE DE POSE DES RADIATEURS
PLAATSINGSWIJE VAN DE RADIATOREN
FITTING INSTRUCTIONS**

**ISTRUZIONI PER L'INSTALLAZIONE DEI RADIATORI
GUIA DE INSTALACION DE RADIADORES
BEFESTIGUNGSHINWEISE HEIZKOORPER**

1




2




RÉFÉRENCE	A	B	Kg
XXXX-075-150	1450	700	24
XXXX-075-200	1950	1200	26
XXXX-100-180	1750	1000	32
XXXX-100-200	1950	1200	31
XXXX-100-220	2150	1400	29
XXXX-125-200	1950	1200	40
XXXX-125-220	2150	1400	39
XXXX-150-180	1750	1000	40
XXXX-150-200	1950	1200	44
XXXX-150-220	2150	1400	44
XXXX-200-200	1950	1200	53
XXXX-200-220	2150	1400	53
XXXX-100-180	1750	1000	44








3




4




5




6




7







①




③




④



②



⑤



⑥